



Wall Mounting Instructions

Step 1

Using the template provided mark on the wall where the holes need to be drilled (245mm apart).

Step 2

Using an appropriate drill, drill two holes in the marked positions approximately 50mm deep using an 8mm masonry drill bit.

Step 3

Insert 8mm raw plugs into the holes then push 5mm screws through the holes in the cobra clips and into the raw plugs. Tighten the screws with a screwdriver taking care to keep the cobra clips in the correct position.

Step 4

Clip the Rinse Pimp into position as shown in diagram.

